

# CONTENTS

<b>1.UNPACKING AND CHECKING THE EQUIPMENT.....</b>	<b>1</b>
1.1 Supplied Accessories.....	1
1.2 Standard Accessories.....	2
1.3 Optional Accessories.....	2
<b>2.BATTERY INFORMATION.....</b>	<b>3</b>
2.1 Charging the Battery Pack.....	3
2.2 Charger Supplied.....	3
2.3 Use Caution with the Li-ion Battery.....	3
2.4 How to Charge.....	4
2.5 Normal Charging Tips.....	5
2.6 How to Store the Battery.....	6
<b>3. PREPARATION.....</b>	<b>7</b>
3.1 Installing / Removing the Battery.....	7
3.2 Installing / Removing the Antenna.....	7
3.3 Installing / Removing the Belt Clip.....	8
3.4 Installing the Additional Speaker/Microphone (Optional).....	8
<b>4. Radio Overview.....</b>	<b>9</b>
4.1 Status Indications.....	10
4.2 Programmed Key.....	10
4.3 Hot Key Setting for PF1, PF2, PF3, P1, P2.....	12
4.4 Combination key function.....	12
<b>5.BASIC OPERATIONS.....</b>	<b>13</b>
5.1 Power on the Radio.....	13
5.2 Adjust Volume.....	13
5.3 Main band/Sub band switch.....	13
5.4 VFO/Channel switch.....	13
5.5 Set up VFO frequency.....	13
5.6 Select a Channel.....	13
5.7 New channel.....	14
5.8 Delete Channel.....	14
5.9 Receiving and Responding to a Radio Call.....	14