

2. BATTERY INFORMATION

-  **NOTE** » Trickle charging (Pre-Charging Mode) time cannot last beyond 30 minutes. If the indicating lamp still blinks red after 30-minute trickle-charging, it means that the charger cannot charge the battery correctly. Please check whether the battery or charger is damaged.

2.6 How to Store the Battery

- a. If the battery needs to be stored, keep it in status of 80% discharged.
- b. It should be kept in low temperature and dry environment.
- c. Keep it away from hot places and direct sunlight.

-  **NOTE** » **Do not short circuit the battery terminals.**
- » **Never attempt to remove the casing from the battery pack.**
- » **Never store the battery in unsafe surroundings, as a short may cause an explosion.**
- » **Do not put the battery in a hot environment or throw it into a fire, as it may cause an explosion.**