4. RADIO OVERVIEW

Emergency Alarm Key (PF3)
Channel Switch
POWER/VOL
Antenna
LED Status Indicator
LCD
Menu key
Exit Key
P1 key/ P2 key
Speaker
MIC Input

PTT Button
Speaker/Mic Jacks
[PF1] top Key
[PF2] bottom Key