

7. MAIN MENU FUNCTIONS

(7) TX Timer

30S-240S: The TX will be limited in the set time. When this time is reached, the radio will auto stop transmission.

OFF: Turn off the TX time limit, and there is no limit for the transmission time.

(8) Max Vol Level

Indoor: Very low volume, suitable for the indoor use.

Level 1-8: Set up the maximum volume level.

(9) Ear Max Vol

Indoor: Very low volume, suitable for indoor use.

Level 1-8: Set up the maximum volume level for earphone. When the radio connect with earphone, it will auto change to earphone maximum volume.

(10) Enhanced Sound

It will allow you set up the microphone audio pitch.

Normal: Low pitch.

Enhance: High pitch.

(11) Language

Choose the Chinese or English.

(12) Menu Exit Time

5S-60S: When enter the menu, the radio will stay at the menu in the set time. When the time is reached, the radio will auto exit the menu.

(13) Start Display

Picture: The radio will display an AnyTone picture when powered on.

Character: The radio will display the characters set up in PC software when powered on.

Customer's Pic: The radio will display the picture uploaded by PC software. In CPS -Tool -Boot Image, it will allow you upload a Power-on Picture.

(14) Background

Default Picture: In standby, the radio will display default picture.

Customer's Pic: The radio will display the picture uploaded by PC software. In CPS-Tool-Standby BK Picture, it will allow you upload a standby background picture.

(15) ChanFont Color

White: In standby, the channel and other information will display color in white.

Black: In standby, the channel and other information will display color in black.

(16) Main Ch

Channel A: The upper displayed channel will be set to be the main channel.