

## 8. RESET

- a. Power off the radio firstly.
- b. Then power it on while holding the [PTT] and the [PF1] button below the PTT at the same time.
- c. The radio will start up with a note on the display – “Are you sure you want to initialize radio?”  
Press Exit to exit the reset and power on the radio.  
Press Confirm to proceed the reset, it will come with a screen display note – Initialize Radio.
- d. After a re-start the radio will display the setting of time zone and the date and the time. Use the up-down key to set the current year. Move to the month by pushing the **P1** key. Set the month, and use the **P1** key to move forward each step. Once done, click the Confirm key to save the date and time.

Please remember set up the time zone to avoid the date/time error.

Make sure the codeplug is saved to PC before your do the update and reset.